

'CR3000 Series Datalogger

'Declare Public Variables

```
Public PTemp_C
Public relayset(16)
Public CO2(20)
Public O2(20)
Dim j
Public AirTemp
Public SoilTemp
Public ChamberNumber As Long
Public S_Scans
```

'Create boolean variables for do/don't do logic
Public SampleNow As Boolean

'Declare Units
Units PTemp_C=Deg C
Units CO2=Volts
Units O2=Volts
Units AirTemp=Deg C
Units SoilTemp=Deg C

'Define Data Tables
DataTable (MasterTB,1,-1)
 DataInterval (0,5,min,10)
 Sample (1,ChamberNumber,Long)
 Average (1,PTemp_C,FP2,False)
 Sample (20,CO2(),FP2)
 Sample (20,O2(),IEEE4)
 Sample (1,AirTemp,FP2)
 Sample (1,SoilTemp,FP2)
EndTable

Sub SampleNow
 For j = 1 To 20
 VoltDiff (O2(j),1,mV5000,1,True ,0,_60Hz,0.005,0)
 VoltDiff (CO2(j),1,mV5000,2,True,0,_60Hz,.4,0)
 Delay (0,12,sec)
 Next j
EndSub

'Main Program
BeginProg
 Scan (1,min,0,0)
 PanelTemp (PTemp_C,_60Hz)
 'Relay sequencing section
 If TimeIntoInterval (0,30,min) Then
 relayset(6) = false.....chamber 6 opens
 relayset(12) = false.....sample intake 6 closes
 relayset(7) = true.....sample intake 1 opens

```

TCDiff (AirTemp,1,mV20c,13,TypeT,PTemp_C,True,0,_60Hz,1,0).....chamber 6 air temp
TCDiff (SoilTemp,1,mV20c,14,TypeT,PTemp_C,True,0,_60Hz,1,0).....chamber 6 soil temp
EndIf

If TimeIntoInterval (1,30,min) Then
    relayset(1) = true.....chamber 1 closes
    ChamberNumber = 1.....chamber number 1 recorded
EndIf

If TimeIntoInterval (5,30,min) Then
    relayset(1) = false.....chamber 1 opens
    relayset(7) = false.....sample intake 1 closes
    relayset(8) = true.....sample intake 2 opens
    TCDiff (AirTemp,1,mV20c,3,TypeT,PTemp_C,True,0,_60Hz,1,0).....chamber 1 air temp
    TCDiff (SoilTemp,1,mV20c,4,TypeT,PTemp_C,True,0,_60Hz,1,0).....chamber 1 soil temp
EndIf

If TimeIntoInterval (6,30,min) Then
    relayset(2) = true 'Chamber 2 closes
    ChamberNumber = 2
EndIf

If TimeIntoInterval (10,30,min) Then
    relayset(2) = false 'Chamber 2 opens
    relayset(8) = false 'Intake 2 closes
    relayset(9) = true 'Intake 3 opens
    TCDiff (AirTemp,1,mV20c,5,TypeT,PTemp_C,True ,0,_60Hz,1,0)
    TCDiff (SoilTemp,1,mV20c,6,TypeT,PTemp_C,True ,0,_60Hz,1,0)
EndIf

If TimeIntoInterval (11,30,min) Then
    relayset(3) = true 'Chamber 3 closes
    ChamberNumber = 3
EndIf

If TimeIntoInterval (15,30,min) Then
    relayset(3) = false 'Chamber 3 opens
    relayset(9) = false 'Intake 3 closes
    relayset(10) = true 'Intake 4 opens
    TCDiff (AirTemp,1,mV20c,7,TypeT,PTemp_C,True ,0,_60Hz,1,0)
    TCDiff (SoilTemp,1,mV20c,8,TypeT,PTemp_C,True ,0,_60Hz,1,0)
EndIf

If TimeIntoInterval (16,30,min) Then
    relayset(4) = true 'Chamber 4 closes
    ChamberNumber = 4
EndIf

If TimeIntoInterval (20,30,min) Then
    relayset(4) = false 'Chamber 4 opens
    relayset(10) = false 'Intake 4 closes
    relayset(11) = true 'Intake 5 opens
    TCDiff (AirTemp,1,mV20c,9,TypeT,PTemp_C,True ,0,_60Hz,1,0)

```

```
    TCDiff (SoilTemp,1,mV20c,10,TypeT,PTemp_C,True ,0,_60Hz,1,0)
EndIf
```

```
If TimeIntoInterval (21,30,min) Then
    relayset(5) = true 'Chamber 5 closes
    ChamberNumber = 5
EndIf
```

```
If TimeIntoInterval (25,30,min) Then
    relayset(5) = false 'Chamber 5 opens
    relayset(11) = false 'Intake 5 closes
    relayset(12) = true 'Intake 6 opens
    TCDiff (AirTemp,1,mV20c,11,TypeT,PTemp_C,True ,0,_60Hz,1,0)
    TCDiff (SoilTemp,1,mV20c,12,TypeT,PTemp_C,True ,0,_60Hz,1,0)
EndIf
```

```
If TimeIntoInterval (26,30,min) Then
    relayset(6) = true 'Chamber closes
    ChamberNumber = 6
EndIf
```

```
SDMCD16AC (relayset(),1,0)
```

```
'Sample Subroutine
```

```
If TimeIntoInterval (1,30,min) Then Call SampleNow.....sample from Chamber 1
If TimeIntoInterval (6,30,min) Then Call SampleNow..... sample from Chamber 2
If TimeIntoInterval (11,30,min) Then Call SampleNow.....sample from Chamber 3
If TimeIntoInterval (16,30,min) Then Call SampleNow.....sample from Chamber 4
If TimeIntoInterval (21,30,min) Then Call SampleNow.....sample from Chamber 5
If TimeIntoInterval (26,30,min) Then Call SampleNow.....sample from Chamber 6
```

```
S_Scans = status.skippedscan(1,1)
```

```
CallTable(MasterTB)
```

```
SetStatus ("skippedscan",0)
```

```
NextScan
EndProg
```